

# **EPA's Hg Gas Traceability Approach for Source Emissions Measurement and Monitoring**



**Jeff Ryan**

**U.S. Environmental Protection Agency**

**Office of Research and Development**

**[ryan.jeff@epa.gov](mailto:ryan.jeff@epa.gov)**



**12<sup>th</sup> International Conference on Mercury as a Global Pollutant**


**June 14-19, 2015**

**Jeju, Korea**

# Overview

---


- US EPA Hg emissions regulations
- Hg emissions measurement requirements and approaches
- Hg Reference Standards and Traceability
- Need for International consensus Hg Gas Standards?
- Summary messages



# US Regulations with Mercury Emissions Measurement and Monitoring Requirements

---

- Mercury Air Toxics Standards (MATS) for power plant boilers
- Portland Cement MACT
- Industrial Boiler MACT
- Commercial & Industrial Incinerator MACT
- Sewage Sludge Incinerator MACT



# Mercury Emissions Measurement Quality

---

- EPA regulations specify the use of National Institute of Standards and Technology (NIST) traceable reference materials to ensure the quality of Hg emissions measurements
  - Liquid standards
  - Gaseous elemental mercury ( $\text{Hg}^0$ )
  - Gaseous oxidized mercury ( $\text{HgCl}_2$ )
- EPA defines NIST traceability requirements
- **These standards provide a common and consistent quantitative basis for mercury emissions reporting**



# EPA Hg Measurement Options


---

- Two primary mercury emissions measurement options for stationary sources:
  - **Continuous Emissions Monitoring Systems (CEMS)**
  - Sorbent trap systems
- All methods require NIST traceable reference materials



# Method 30B/PS 12B

- Performance-based
  - Amenable to new sorbents, equipment, and analytical technologies
- Principle
  - Gas sampled through paired, in-stack 2-section sorbent traps
  - Analysis by any system meeting performance criteria
  - Liquid Hg standards used for calibration
  - Gaseous Hg<sup>0</sup> used for trap spiking





# Mercury CEMS Background

---



- Hg CEMS measure total gaseous Hg
  - Elemental ( $\text{Hg}^0$ )
  - Oxidized ( $\text{Hg}^{2+}$ ); typically converted to elemental Hg for measurement
- Use of NIST-traceable elemental and oxidized Hg gas standards required for emissions measurement QA/QC



# Hg CEMS QA/QC

---

- QA/QC Requirements for initial Hg CEMS certification
  - 7-day drift test – *with Hg<sup>0</sup> or HgCl<sub>2</sub>*
  - Measurement error test (at 3 levels) – *with Hg<sup>0</sup> and HgCl<sub>2</sub>*
  - Relative accuracy test (RATA) compared against a reference test method (typically 30B)
- QA/QC Requirements for continued Hg CEMS operation
  - Daily drift check *with Hg<sup>0</sup> or HgCl<sub>2</sub>*
  - Weekly System Integrity Check *with HgCl<sub>2</sub>*
  - Quarterly Measurement Error test – *with Hg<sup>0</sup> and HgCl<sub>2</sub>*
  - Annual RATA



# Gases for Calibration and QA/QC


---

- For the most part, CEMS vendors are using  $\text{Hg}^0$  and  $\text{HgCl}_2$  mercury gas generators to provide reference gas standards for their instruments
- $\text{Hg}^0$  compressed gas cylinders emerging as a viable option
- Working range of Hg gas concentrations:  $0.2 - 350 \mu\text{g}/\text{m}^3$



# Elemental ( $\text{Hg}^0$ ) Gas Generators

Produce known concentrations of  $\text{Hg}^0$  gas by passing a controlled gas stream through the headspace of a temperature controlled reservoir of Hg and then blending with a dilution gas stream



# Oxidized ( $\text{HgCl}_2$ ) Gas Generators

---

- Two types currently in use:
  - Evaporative  $\text{HgCl}_2$  generator, which produces gas by vaporization of known concentration of a  $\text{HgCl}_2$  solution and quantitatively mixes with a diluent gas
  - Device that converts output from an elemental Hg generator to  $\text{HgCl}_2$  by reacting with  $\text{Cl}_2$



# EPA Gas Standard NIST Traceability

---


- EPA establishes what constitutes “*NIST Traceability*”
- EPA defines **NIST traceability** of gas standards as an “*unbroken chain of comparisons*” to a primary NIST standard
- Gas standards are traceable to a measured, not theoretical, concentration
- Not so easy for Hg ...
- EPA has published traceability protocols used to establish NIST traceability of both elemental and oxidized mercury gas standards
- **Lack of method for direct measurement of  $\text{HgCl}_2$  precluded ‘unbroken chain of comparisons’ for certification of oxidized Hg gas generators**

# Traceability for Hg<sup>0</sup> Generators

---


- NIST certifies '***NIST Prime***' generators which are used to certify '***Vendor Primes***' generators that a manufacturer uses to certify '***Field Reference or User***' generators contained in the Hg CEMS
- Calculations provided to determine combined, expanded uncertainty of the generated concentrations
- **Uncertainty of User Generators must be  $\leq 5\%$**

Unbroken Chain of Comparisons




# Traceability for Evaporative $\text{HgCl}_2$ Generators

- Based on traceability and uncertainty of the following components:
  - Working solution concentration
  - Liquid feed rates
  - Carrier gas flow rate
- Calculations provided to determine combined, expanded uncertainty of the generated concentrations
- **No direct measurement or verification**
- Resulting Uncertainty  $\leq 10\%$
- **“Correction Factor”** to allow agreement with  $\text{Hg}^0$



# Traceability for Generators That Convert $\text{Hg}^0$ to $\text{HgCl}_2$


- Combined uncertainty of the  $\text{HgCl}_2$  standard is based on the uncertainty of the elemental Hg generator, the water vapor dilution (where applicable), and the chlorine dilution
- Calculations provided to determine combined, expanded uncertainty of the generated concentrations
- **No direct measurement or verification**
- Resulting Uncertainty  $\leq 10\%$





# Elemental vs. Oxidized Hg: The Discrepancy

---



- Recognized, but not understood, 7-10% discrepancy between  $\text{Hg}^0$  and evaporative  $\text{HgCl}_2$  gas standards
  - *Many have tried ... Many have failed ...*
- Confounded by the lack of a reliable  $\text{HgCl}_2$  measurement technique
- The “discrepancy” issue for evaporative  $\text{HgCl}_2$  generators won’t go away ...
  - EPA and NIST are continuing to collaborate to resolve the issue
- EPA and NIST are exploring the “naming” of evaporative  $\text{HgCl}_2$  generator outlet concentrations as an option
- EPA’s need is for  $\text{HgCl}_2$  standards to be of the same quantitative quality as the  $\text{Hg}^0$  gases! (i.e.,  $\leq 5\%$  U)

# Need for International Consensus Hg Standards

---

- Emerging need for the International use of Hg gas standards as International use of Hg CEMS expands:
  - U.S. companies now selling Hg CEMS worldwide
  - Global Mercury Partnership of Minamata Convention supporting development of Hg measurement/monitoring capabilities
  - EPA Hg Methods promoted by UNEP and being adopted internationally
- Need for International Hg measurements to be comparable
- Practical options for providing traceable Hg gas standards needed
- International Consensus Hg Gas Standards seems logical

# Summary ...

---

- Hg<sup>0</sup> and HgCl<sub>2</sub> gases of the same quality is EPA's absolute need
  - Uncertainties  $\leq 5\%$
  - Based on measured, not theoretical, output
- EPA sees resolution of the HgCl<sub>2</sub> evaporative generator “discrepancy” as a critical issue
  - EPA and NIST will continue to tackle the problem, but welcome help
- A sound, direct HgCl<sub>2</sub> measurement approach is also critical
- Expanding International use of Hg CEMS warrants consideration of establishing International Consensus Hg Gas Standards

# Questions ...

The views expressed in this presentation are those of the author and do not necessarily represent the views or policies of the U.S. Environmental Protection Agency

Any mention of trade names, products, or services does not imply an endorsement by the US Government or the United States Environmental Protection Agency. EPA does not endorse any commercial products, services, or enterprises.