

Surface Disinfection by UVC

Bench Scale Study and Field Implementation Considerations

Lukas Oudejans, Ph.D.

Katherine Ratliff, Ph.D.

Center for Environmental Solutions and Emergency Response
Office of Research and Development
U.S. Environmental Protection Agency

IUVA Webinar Enhancing the New Normalcy with UV Disinfection - Transportation




EPA – FIFRA and UV Lights

UV lights are federally regulated in the U.S. by EPA under FIFRA as a device if sold/distributed with claims for its use for preventing, destroying, repelling or mitigating any pests

Must comply with certain statutory and regulatory requirements

- UV device claims must be supported by testing with that specific device including testing for any pathogens they list
- EPA does not accept general claims like “germicidal” or unqualified “germ” claims
- False or misleading claims cannot be made




- Growing interest in UVC for surface and aerosol disinfection as a result of pandemic
- Emerging UVC products are being widely marketed
- Increasing technical support requests for evaluating UVC technologies (e.g., from public transportation agencies)
- Feasibility of UVC in complex environments is relatively unknown



*New York Metropolitan Transport Authority
invested \$1 million on devices from Puro
Lighting for their trains and buses*

Problem Definition (cont.)

- UVC can be an effective approach to reduce exposure to virus on
 - Surfaces
 - Aerosols
- Complementary to regular disinfection and/or cleaning procedures
- Not all UV is equal
 - Single wavelength
 - Broad wavelength
 - Continuous vs Pulsed/Flash



UV radiation is classified as a human carcinogen by US Department of Health and Human Services and the World Health Organization



- Is UVC effective in inactivating SARS-CoV-2?
 - Can we consider surrogate (viruses)
- What parameters impact efficacy?
 - Dose (Intensity, distance, and time)
 - Material
 - Dry / wet droplets
 - Saliva composition
- What UVC doses are achievable in the field?





LA Metro Field Test

- LA Metro field study (August 2020)
 - Evaluate practicality of a UV-C emitted pulsed xenon light: ease of use, setup time, durability, electrical load, functionality
 - Evaluate dose in field testing
- EPA supplied MS2-inoculated stainless-steel coupons to incorporate in field test
- LA Metro measured UV dose for each coupon location / exposure






- Measured range of UVC doses in LA Metro tests: $\leq 4.0 \text{ mJ/cm}^2$
- Lowest doses at locations outside of direct line of sight or at large distances
- Highest dose for location at $\sim 60''$ directly in front of light, 30 min exposure time
- *No significant reduction in MS2* on coupons exposed to UVC in LA Metro test*
 - Laboratory tests needed to understand this lack of virus inactivation



Source: AP


* MS2: Non-enveloped bacteriophage; BSL-1 organism; high resistance & persistence, fast and easy analysis

- Field study with stakeholders (LA Metro)
- Bench-scale studies:
 - Determine efficacy of UV-C light emitting devices against SARS-CoV-2 virus
 - Pulsed Xenon light
 - UV-C LED (275 nm)
 - Materials: ABS plastic, stainless steel, bus seat fabric
 - Assess efficacy in applied settings






SARS-CoV-2 Efficacy Results Pulsed Xenon



LA Metro dose (at 30 min, ~60")

- High log reductions for smooth materials (ABS plastic and stainless steel)
- Low log reductions for rough, porous surface (bus seat fabric)
 - Virus shielded from UVC light within material fibers
- SARS-CoV-2 in a dried saliva is most difficult to inactivate
 - Absorption of UVC light in saliva may explain this difference
- LA Metro's highest UVC dose recorded for a surface at 60" distance from a light and a 30 min exposure time was 4.0 mJ/cm²


SARS-CoV-2 Efficacy Results LED



- High log reductions for smooth materials (ABS plastic and stainless steel)
- Low log reductions for rough, porous surface (bus seat fabric)
 - Virus shielded from UVC light within material fibers
- SARS-CoV-2 in a dried saliva is most difficult to inactivate
 - Absorption of UVC light in saliva may explain this difference


A closeup of some of the materials

Milled 304 Stainless Steel (MS2/Phi6 study)




SEM HV: 15.0 kV	WD: 9.95 mm	MIRA3 TESCAN
View field: 39.8 µm	Det: SE	10 µm
SEM MAG: 7.26 kx	Date(m/d/y): 10/14/20	

301 Stainless Steel (SARS-CoV-2)



SEM HV: 15.0 kV	WD: 16.81 mm	MIRA3 TESCAN
View field: 57.8 µm	Det: SE	10 µm
SEM MAG: 5.00 kx	Date(m/d/y): 11/09/20	

Glass Coupon (MS2/Phi6 study)




SEM HV: 15.0 kV	WD: 17.31 mm	MIRA3 TESCAN
View field: 62.4 µm	Det: SE	10 µm
SEM MAG: 4.63 kx	Date(m/d/y): 10/19/20	



SARS-CoV-2 Surrogate Research

Pulsed Xenon Light Inactivation



- Conducted UVC disinfection research with two potential surrogate bacteriophages, MS2 and Phi6
- MS2 is a good surrogate in that it is more difficult to inactivate than SARS-CoV-2

- Summary of bench scale research
 - We estimated UVC doses needed to achieve various log reductions of SARS-CoV-2, and other surrogate viruses, with two light sources
 - UVC dose conditions depend on multiple variables
 - Lack of established methods makes direct comparisons with (new) literature challenging
 - For the tested light sources, the required doses for 3 log reduction (99.9%) could only be obtained at relatively short (30" or shorter) distances for operationally feasible exposure times (<60 min)

- Considerations for surface disinfection
 - Implementation of UVC requires design and engineering solutions to deliver effective doses
 - Challenge to do this in complex environments with permanent fixtures
 - Use of multiple lights at various angles or moving lights may overcome single light approaches
 - Inactivation of a virus on non-smooth surfaces (fabric, carpet etc) will remain a challenge
 - Viruses may still be able to “hide” in crevasses or canyons on otherwise smooth surfaces



Acknowledgments

- SARS-CoV-2 studies:
 - Battelle: William Richter, Michelle Sunderman, Megan Howard
- MS2 and Phi6 studies:
 - Jacobs Technology Inc.: Ahmed Abdel-Hady, Mariela Monge, Denise Aslett, Dahman Touati
 - EPA Region 9: Jason Musante
 - Los Angeles Metro: Blakeley Ficenec, Nizar Madanat, Cindy Amaral
 - NY MTA
- EPA Project Team:
 - Shannon Serre, Christine Tomlinson (Office of Emergency Management)
 - Shawn Ryan, Worth Calfee (ORD/CESER)
 - Yvette Hopkins (Office of Enforcement and Compliance)
 - Diane Isbell (Office of Pesticide Programs)



Points of Contact

Lukas Oudejans, Oudejans.lukas@epa.gov

Katherine Ratliff, Ratliff.Katherine@epa.gov

ORD/CESER/HSMMD



<https://www.epa.gov/healthresearch/research-covid-19-environment>

DISCLAIMER: The United States Environmental Protection Agency (EPA), through its Office of Research and Development, funded and managed the research described. This presentation was peer and administratively reviewed and has been approved for presentation as an Environmental Protection Agency document. It does not necessarily reflect the views of the Environmental Protection Agency. No official endorsement should be inferred. This presentation includes photographs of commercially-available products. The photographs are included for purposes of illustration only and are not intended to imply that EPA approves or endorses the product or its manufacturer. EPA does not endorse the purchase or sale of any commercial products or services. Data presented herein did not undergo a formal quality assurance review as outlined in “U.S. EPA Office of Research and Development’s Quality Management Plan for Scientific Research”. If these data are included in future EPA reports or other publications, they will be subjected to this review.